#### 1-Find your mac address.

Answer: - write in CMD this command getmac or ipconfig /all

```
C:\Users\DREAMSsss>ipconfig /all
Windows IP Configuration
  Host Name . . .
                   . . . . . . . . : DESKTOP-VLV4CKH
  Primary Dns Suffix . . . . . :
  Node Type . . . . . . . : Mixed IP Routing Enabled . . . . . : No
  WINS Proxy Enabled. . . . . . : No
  DNS Suffix Search List. . . . . : home
Ethernet adapter Ethernet:
  Media State . . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
  Description . . . . . . . . : Broadcom NetXtreme Gigabit Ethernet Plus
  Physical Address. . . . . . . : C8-D3-FF-72-35-1F
  DHCP Enabled. . . . . . . . : Yes
  Autoconfiguration Enabled . . . . : Yes
Wireless LAN adapter Local Area Connection* 8:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
  Description . . . . . . . . : Microsoft Wi-Fi Direct Virtual Adapter
  Physical Address. . . . . . . : 7C-B0-C2-97-C6-E8
  DHCP Enabled. . . . . . . . . : Yes
  Autoconfiguration Enabled . . . . : Yes
Wireless LAN adapter Local Area Connection* 10:
  Media State . . . . .
                          . . . . : Media disconnected
   Connection-specific DNS Suffix .:
  Description . . . . . . . . : Microsoft Wi-Fi Direct Virtual Adapter #2
  Physical Address. . . . . . . : 7E-B0-C2-97-C6-E7
  DHCP Enabled. . . . . . . . . . . Yes
  Autoconfiguration Enabled . . . . : Yes
```

#### 2- Find your real IP addresses.

Answer :- https://whatismyipaddress.com/

# What Is My IP Address?

My Public IPv4: 104.28.245.5

My Public IPv6: 2a09:bac5:30cd:1eb::31:188 @

My IP Location: Cairo, C EG

My ISP: CloudFlare Inc. @

Or write in CMD this command ---> nslookup myip.opendns.com resolver1.opendns.com

C:\Users\DREAMSsss>nslookup myip.opendns.com resolver1.opendns.com

Server: dns.sse.cisco.com Address: 2620:119:35::35

Name: myip.opendns.com

Address: 2a09:bac5:30cd:1eb::31:188

C:\Users\DREAMSsss>

## 3- Find your private IP addresses.

write in CMD this command ipconfig

```
C:\Users\DREAMSsss>ipconfig
Windows IP Configuration
Ethernet adapter Ethernet:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Wireless LAN adapter Local Area Connection* 8:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Wireless LAN adapter Local Area Connection* 10:
  Media State . . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Wireless LAN adapter Wi-Fi:
  Connection-specific DNS Suffix . : home
  IPv6 Address. . . . . . . . . : fd8c:15c7:ebb6:3e00:c555:7964:2573:1d4d
  IPv6 Address. . . . . . . . : fd01:db8:1111::2
  IPv6 Address. . . . . . . . . : fd01:db8:1111::3
  Temporary IPv6 Address. . . . . : fd8c:15c7:ebb6:3e00:60ad:d1ca:4504:f4ec
  Link-local IPv6 Address . . . . : fe80::6149:5e19:b065:5e05%18
  IPv4 Address. . . . . . . . . : 192.168.1.6
  Subnet Mask . . . . . . . . : 255.255.255.0
  Default Gateway . . . . . . . : 2606:4700:d0::a29f:c009
                                  192.168.1.1
Ethernet adapter Bluetooth Network Connection:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
:\Users\DREAMSsss>
```

## 4- Change private IP address by using CMD.

```
Administrator: Command Prompt
Microsoft Windows [Version 10.0.19045.4894]
(c) Microsoft Corporation. All rights reserved.
C:\Windows\system32>netsh interface ipv4 set address name="Wi-Fi" static 192.168.1.15 255.255.255.0 192.168.1.1
C:\Windows\system32>ipconfig
Windows IP Configuration
Ethernet adapter Ethernet:
  Media State . . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
Wireless LAN adapter Local Area Connection* 8:
  Media State . . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
Wireless LAN adapter Local Area Connection* 10:
  Media State . . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
Wireless LAN adapter Wi-Fi:
  Default Gateway . . . . . . . : 192.168.1.1
Ethernet adapter Bluetooth Network Connection:
                                  . . : Media disconnected
  Media State . . . . . . . . . . . : Connection-specific DNS Suffix . :
C:\Windows\system32>
```

#### 5- Find current session and ports on your device.

```
C:\Windows\system32>Netstat -n
Active Connections
 Proto Local Address
                     Foreign Address
                                      State
     127.0.0.1:56561
                     127.0.0.1:4843
                                     SYN SENT
 TCP
     192.168.1.15:56460
                     84.17.42.168:443
                                     ESTABLISHED
     192.168.1.15:56536
                     20.189.173.18:443
                                     TIME WAIT
 TCP
     192.168.1.15:56554
                                     TIME WAIT
                     20.13.204.76:443
 TCP
     192.168.1.15:56555
                                     TIME WAIT
                     20.13.204.76:443
 TCP
      [2606:4700:110:8cd0:d9da:490f:9160:3e45]:56413 [2603:1020:805:3::401]:443 ESTABLISHED
 TCP
      2606:4700:110:8cd0:d9da:490f:9160:3e45]:56414
                                       [2603:1020:805:3::401]:443 ESTABLISHED
 TCP
      [2606:4700:110:8cd0:d9da:490f:9160:3e45]:56416
                                       TCP
      [2606:4700:110:8cd0:d9da:490f:9160:3e45]:56417
                                       TCP
      [2606:4700:110:8cd0:d9da:490f:9160:3e45]:56418
                                       2606:4700:110:8cd0:d9da:490f:9160:3e45]:56419
 TCP
                                        TCP
                                       [2606:4700:110:8cd0:d9da:490f:9160:3e45]:56449
 TCP
      [2606:4700:110:8cd0:d9da:490f:9160:3e45]:56450
                                       TCP
      [2606:4700:110:8cd0:d9da:490f:9160:3e45]:56477
                                       TCP
      [2606:4700:110:8cd0:d9da:490f:9160:3e45]:56503
                                       TCP
      2606:4700:110:8cd0:d9da:490f:9160:3e45]:56504
                                        TCP
      [2606:4700:110:8cd0:d9da:490f:9160:3e45]:56505
                                       TCP
                                       [2606:4700:4400::6812:202f]:443 ESTABLISHED
      [2606:4700:110:8cd0:d9da:490f:9160:3e45]:56516
 TCP
      [2606:4700:110:8cd0:d9da:490f:9160:3e45]:56523
                                       TCP
      2606:4700:110:8cd0:d9da:490f:9160:3e45]:56537
                                       TCP
      [2606:4700:110:8cd0:d9da:490f:9160:3e45]:56538
                                       TCP
      [2606:4700:110:8cd0:d9da:490f:9160:3e45]:56553 [2a00:1450:4006:810::2004]:443 CLOSE WAIT
C:\Windows\system32>
```

#### 6-Find The IP of the domain Yahoo.com.

```
C:\Windows\system32>nslookup yahoo.com
Server: warp-svc
Address: fd01:db8:1111::2
Non-authoritative answer:
Name:
       yahoo.com
Addresses: 2001:4998:24:120d::1:0
         2001:4998:24:120d::1:1
         2001:4998:44:3507::8001
         2001:4998:124:1507::f000
         2001:4998:44:3507::8000
         2001:4998:124:1507::f001
         74.6.231.20
         74.6.143.25
         98.137.11.164
         98.137.11.163
         74.6.143.26
         74.6.231.21
C:\Windows\system32>
```

# **Packet Tracer Topology:**



